

Pengo 4k Grabber Firmware Update Guide

1. Unzip the RAR file



Upgrade
App.rar


*This version is for Windows only

*Different Windows version might have different images.

2. After it's unzipped, execute either file "Setup.msi" or "setup.exe"




setup.exe




Setup.msi


3. Set up process from Setup.msi file




4. Select Next




5. Select designated location and press Next




6. Installation complete, press Close



7. Go where the file was saved and press Pengo.exe to execute the file




8. Once the software is turn on, it will look like the below image.




9. Plug in the 4K HDMI Grabber and the image will show you something like below image. On the right upper corner, press UPDATE. NOTE: Please make sure you DO NOT have a source plugged into the Grabber, make sure you do not have any other applications running on the background that might affect the update. Please make sure the grabber and your computer is on it's best and simplest conditions.



10. During the update, please do not remove any cables and turn off any devices.




11. Once it's updated · Please close the application Pengo.exe · Then ALSO unplug and replug our 4K HDMI Grabber



12. In the Video ICON, you can confirm your output and input and capture format.



13. With INPUT/OUTPUT IN, You can view resolution



14. In the VOLUME ICON, you can control the volume into the grabber, but this function is the same as controlling it from your computer.

